

117-Safari Mirror

117-Safari Mirror mounts to Olympic 4x4's 131-Safari Door, or you can mount them to the stock door hinge when you have your factory doors removed. Olympic 4x4 Products are serviced by our factory. We provide answers to installation questions. We ship parts ASAP. Try us before the hassle of returning Olympic 4x4 Products to your retailer or mail order specialist.

For assistance please call (800) 777-0878.

Hardware list:

4	3/8" lock washer
2	3/8" jam nut (short nut)
2	3/8" nut

Parts list:

2	Safari mirror
2	Safari mirror mounting arm

- Step 1. Locate the safari mirror-mounting hole in your safari door, on the doors upper mounting bracket. Note that is a cylinder shape and has a hole through the center. Install safari mirror onto the safari mirror-mounting arm by removing the bolt that is on the backside of the mirror and then attach the mirror to the mounting arm using the bolt you just removed.
- Step 2. Install one of the 3/8" jam nuts and then a lock washer onto the threaded shaft of the safari mirror.
- Step 3. Insert the threaded shaft of the safari mirror through the mirror-mounting bracket that is on your safari door. If installing without safari doors, install the threaded shaft of the safari mirror through the stock door hinge.
- Step 4. Secure safari mirror to safari door, by installing a lock washer and then 3/8" nut onto the threaded portion of your safari mirror that extends through the safari mirror-mounting hole. Photo on the bottom shows how the mirror should be assembled.
- Step 5. Repeat steps 1-4 for opposite side of vehicle.
- Step 6. Adjust mirrors so you can see out of them.

