

DEFENDER TUBE FRONTBUMPER, STAINLESS, 55-06, CJ & WRANGLER



Step (1) Remove the front bumper from the vehicle.
DO NOT DISCARD ORIGINAL HARDWARE.
It will be reused for the new bumper installation.



Step (2) Position the new front bumper up to the frame
and line up the holes to factory mounting
locations. Using the stock bolts and supplied
flat washers secure bumper to vehicle.



For Technical Assistance Contact:
OMIX-ADA Tech Support
Phone: 1-800-449-6649
Email: techsupport@omix-ada.com
Web: www.Omix-Ada.com