



Installation Instruction

Windsheild Channel (#90101)

PARTS LIST		
Item #	Description	Qty Needed
1	Windshield Extrusion	2
2	# 8 x 1/2 Phil Pan Screw	11

Directions:

Center Windshield Retainer (Item #1) on top of windshield frame. Butt the ends together and center, aligning with the hole in the center of the windshield frame.

Use retainer as template to mark and drill 1/8" holes into windshield frame.

Secure retainer to vehicle using (Item #2) # 8 x 1/2" Phil Pan Sheet Metal Screw.

LIMITED WARRANTY

All sewn goods manufactured by Smittybilt Automotive are warranted for 90 days from date of purchase. Warranty covers only defects in materials and workmanship. Goods damaged by improper installation, improper maintenance, misuse, accidents, Acts of God, vandalism, etc. are not covered.

Remedies available in the event of a bona fide warranty situation are limited to the repair or replacement of defective merchandise manufactured by Smittybilt Automotive.

If you have a warranty claim, call our customer service number listed below for instructions. You must retain proof of purchase to be submitted along with the merchandise returned. If warranty repairs are performed by Smittybilt Automotive, the repaired item will be sent back to you freight prepaid.

Do not return goods without prior authorization from our customer service department.

For Technical Support/Warranty Information please call 310-762-9944