



[www.HylineOffroad.com](http://www.HylineOffroad.com)

1507C West Park Avenue • Perkasie, PA 18944  
Tel: 215/257-4323 • Fax: 215/257-4384 • 800-HYLINE 1 (800/495-4831)

## **Proudly Made In USA**

### **Installation Instructions:**

JK Oversized Tire Mount  
Part Number: **JK-200TM**

### **Vehicle Fitment:**


Fits onto Jeep Wrangler 07-  
Present

### **Parts List**

**Qty:**

- 1 JK Oversize Tire Mount**
- 1 Third Brake Light Plate**
- 3 ½"-20 Nuts**
- 3 ½" Flat Washers**

### **Tools Needed**



**Lug Nut Wrench  
3/4" Deep Socket**

**Congratulations on your purchase of the Hyline Offroad JK Oversized Tire Mount. All of our products are completely manufactured in our facility located in Perkasie, PA. They are designed and engineered by Offroad enthusiasts just like you to be rock solid at an affordable price. Hyline Offroad would like to thank you for your recent purchase and look forward to serving you in the future.**

***Hyline Offroad Staff***

# PLEASE READ INSTRUCTIONS BEFORE BEGINNING INSTALLATION

**IMPORTANT:** We do not recommend installing any tire larger than 35" in Diameter. Doing so may cause damage to your Jeep's tailgate hinges.

## **JK Oversized Tire Mount**

**Step 1 -** Using the Lug Wrench remove the stock tire from vehicle. You will NOT be removing the Stock Tire Carrier from the Jeep.

**Step 2 -** If you're installing a 2" Round LED Third Brake Light you can cut the existing brake light wire and splice following the light manufacturers instructions. If you're not installing a Third Brake Light you can leave the wire as is.

**Step 3 -** Install the Hyline Oversize Tire Mount onto the existing tire carrier by sliding the existing wheel studs through the holes of the Hyline Tire Mount and use 3 supplied flat washers and nuts to install.

**Step 4 -** You can now mount your new oversize tire onto the Hyline Tire Mount. We've already pre-installed the wheel studs so you don't have to. You may reuse your Lug Nuts.

**Step 5 -** If installing a 2" Round LED Third Brake Light you can do so by first inserting the rubber grommet into the hole in the center of the Hyline Oversized Tire Mount, then push in the LED Light and wire.

Send your OFFROAD pictures to [pics@HylineOffroad.com](mailto:pics@HylineOffroad.com) . If we choose any one of your pictures to be used on our website, We send you a FREE Hyline Offroad T-Shirt.



### **Attention**

Installation instructions provided must be read and followed exactly when installing product. Failure to do so could potentially result in injury or death of any occupants in the vehicle. **WEAR SEAT BELTS AT ALL TIMES WHEN DRIVING!**

Though our products are rugged, they are primarily designed and built to enhance the appearance of the vehicle and will not protect from death or injury in the event of an accident. Adhere to all vehicle manufacturers specifications