

Axial LED Tail Lights - Red Clear (07-17 Wrangler JK) Installation Guide

Installation Time: 20 minutes

Tools Required:

- ✓ Phillips head screwdriver
- ✓ Rag or towel

Factory / Before Pictures:



Installation Instructions:

1. Using phillips head screwdriver, remove two inner screws (closest to spare tire) on driver's side factory tail light



2. Set screws aside for installation of aftermarket taillight

3. Unseat factory taillight from mounting position by pushing gently on the side of the tail light, toward the spare tire



4. Remove the taillight from the mounting location and disconnect the quick-connect by depressing the tab (seen in the picture below) and pulling the two ends apart



5. Clean the area behind where the factory tail light was mounted before installing the aftermarket tail light, if desired



6. Remove the passenger's side factory tail light using the same exact method described for the driver's side taillight







7. Install the driver's side aftermarket tail light first by plugging in the quick-connect



8. Install the tail light to the body by placing the tail light in the mounting location and locking into place by gently

pushing the light away from the spare tire



9. Use the phillips head screwdriver to install the screws removed from the factory tail light - do not overtighten

the screws as this can crack the red tail light plastic



10. Install the passenger's side tail light using the same exact method described for the driver's side taillight



11. Test driving lights, turn signals, brake lights, and reverse lights to ensure that the tail lights are connected correctly



Installed Photos:





Installation Instructions Written by ExtremeTerrain Customer Brian Dunn 09/16/2017