

# MAMMOTH

## 4x4 SUSPENSION PARTS

### Installation Instructions & Warranty Information for Mammoth Wheels

#### Tools Required:

Lug Wrench or 1/2" Breaker Bar or Impact Gun  
1/2" Drive 13/16" (21mm) Socket  
Torque Wrench  
Floor Jack

#### Step 1:

Use your lug wrench or breaker bar and loosen the lug nuts approximately 1/4 of a turn.

Note – If you are using an impact gun, skip to Step 2



#### Step 2:

Lift the vehicle enough with a floor jack so that the tire is no longer making contact with the ground (reference owners' manual for proper jacking points). Once the vehicle is safely supported, remove the lug nuts and factory wheel/tire.




#### Step 3:

With the factory wheel removed, inspect the wheel studs, mounting surface, and wheel hubs for any dirt or rust. If necessary, use a wire brush to clean all surfaces before installing new wheel & tire. Place the new wheel & tire on the vehicle and start threading lug nuts on by hand.



#### Step 4:

Tighten lug nuts until snug and lower vehicle fully. Using a torque wrench and 13/16" socket, tighten the lug nuts to the manufacturers recommended torque specification using the sequence illustrated below. Torqueing the lug nuts is a critical safety measure and should be re-checked after 100 miles of driving when installing new wheels.





**Step 5:**

Once the wheel is properly torqued, Repeat Steps 1-4 for any additional wheels that need installation.

**Caring for your Wheels**

Chrome Wheels – Use mild (non-abrasive) soap and water to regularly clean the wheels. Try to avoid excess brake dust build up and never use harsh wheels cleaners or wheel acid on the chrome finish. Chrome polish may be used to remove oxidation and restore brightness.

Painted Wheels – Use mild (non-abrasive) soap and water to regularly clean the wheels. Try to avoid excess brake dust buildup and harsh chemical cleaners that could potentially damage the clearcoat. Wax may be used on the painted surface to protect the finish.

**Wheel Warranty Information**

**Limited Lifetime Structural Warranty**

ExtremeTerrain.com warrants to the original purchaser that all wheels distributed by ExtremeTerrain.com are free of structural defects in material and/or workmanship for the lifetime of the wheel(s).

**One Year Wheel Finish Warranty**

ExtremeTerrain.com warrants to the original retail purchaser that all wheels distributed by ExtremeTerrain.com will be covered for the period of one-year (12 months) from the original purchase date for issues developing in the finish of the wheel.

Chrome Wheels – Guaranteed against separation and peeling of chrome finish.

Painted Wheels – Guaranteed against paint peeling and separation.