



SYNERGY MFG. 870 INDUSTRIAL WAY, SAN LUIS OBISPO, CA (805) 242-0397

PPM-4012 JK SPARE TIRE RELOCATION BRACKET

Version 1

GENERAL NOTES:

- The Synergy JK spare tire relocation bracket will move the tire up 1" and away from the tail gate 1 1/4", this is necessary when using a larger spare tire or using less offset wheels than stock.
- The 3rd brake light may be obstructed since the tire is move up and a larger spare tire is often used

1. Remove the spare tire
2. Position the new spare tire relocation bracket over the 3 studs that attach the spare tire. Using the supplied nylock nuts and washers, secure the spare tire relocation bracket, torque the nuts to 75 ft-lbs
3. Mount the spare tire to the spare tire relocation bracket using the original lug nuts; torque the lug nuts to 75 ft-lbs.
4. If you are using different lug nuts than stock or a wheel lock nut, make sure that the stud does not bottom out in the nut.