


INSTALLATION INSTRUCTIONS

Universal Security Lockbox #029

Please read and fill out the enclosed warranty registration card to activate your warranty.

PARTS CHECKLIST



TOOLS NEEDED

- Electric drill
- 3/8" Drill bit
- Marker or pencil
- Knife
- ½" Socket and ratchet
- ½" Wrench
- Silicone sealant (Recommended)

PLEASE READ ALL INSTRUCTIONS THOROUGHLY BEFORE STARTING INSTALLATION.

- 1. Install rubber seal on lid and between the hinge leaves. Check lock operation.
- 2. Place the lockbox in the vehicle in the desired mounting location.
- 3. Using a marker or pencil, mark (4) spots through the 3/8" mounting holes in the box.

WARNING!

Make sure that there is nothing under the vehicle that will be damaged by the drill bit when drilling.

- 4. Remove the box. Cut the carpet at the (4) marked holes. Using a 3/8" drill bit, drill out the (4) marked spots in the floor.
- 5. It is recommended to use silicone sealant in any holes drilled in the vehicle to prevent rusting.
- 6. Fasten down the box using the hardware provided. (For security, it is best to insert the bolts from underneath the vehicle.)

Call (970)564-1762 for Technical Support