

Fox 2.0 Performance Series IFP Rear Shock for 1.5-3.5" Lift

Installation Guide for Jeep Wrangler '07-'16 2-Door JK

Installation Time: <1 Hour

Tools Required:

- ✓ Box Cutter/Knife
- ✓ 1/2" Wrench
- ✓ 13mm Socket
- ✓ 16mm Socket
- ✓ 18mm Socket
- ✓ Socket Extension
- ✓ Socket Wrench
- ✓ Torque Wrench

Installation Instructions:

1. Carefully open the package using a box cutter or knife (Figure A) and ensure entire shock hardware is included and undamaged.



Figure A

2. Using an 18mm socket on both sides, remove lower shock bolt on the driver's side (Figure B).



Figure B

3. Using a 16mm socket (longer bolts) and a 13mm socket (shorter bolt), remove bolts from driver's side top shock mount if using a shock extension (Figure C). If removing factory shocks, simply remove two 16mm bolts holding shock pin in place.



Figure C

4. Remove shock and set aside (Figure D).



Figure D

5. Thread first long bolt back into place through the Fox 2.0 shock bar pin (Figure E). Then thread second bolt in place and tighten down.



Figure E

6. Slide the bottom of the Fox 2.0 shock into the shock mount. Insert the factory bolt through the bottom end of the shock and shock bracket on the axle (Figure F).



Figure F

7. Torque the bottom 18mm factory bolt to 56 ft-lbs. Torque the top 16mm bolts to 37 ft-lbs.
8. Repeat steps 2-7 on the rear passenger shock.



Before



After

Installation Instructions Written by ExtremeTerrain Customer J. Sandlin 08/14/2017