

Snyper Gas Tank Skid Plate

Installation Guide for Jeep Wrangler '07-'16 2-Door JK

Installation Time: 1 Hour

Tools Required:

- ✓ Box Cutter/Knife
- ✓ 13mm Socket
- ✓ 18mm Socket
- ✓ Socket Wrench
- ✓ Torque Wrench

Installation Instructions:

1. Carefully open the package using a box cutter or knife (Figure A) and ensure the hardware is included and undamaged.



Figure A

2. Remove the two bolts holding the stock gas tank skid plate to the cross member using an 18mm socket wrench (Figure B). **Note: Do not remove the stock gas tank skid plate.**



Figure B

3. Position the Sniper skid plate and reinstall the two bolts removed in Step 2 loosely (Figure C).



Figure C

4. Install the first bracket of the Snyder skid plate as shown below, using the supplied carriage bolts and a 13mm socket (Figure D). **Note: When installing all carriage bolts, ensure the head is facing the gas tank so that, in case of sudden impact, the bolt will not penetrate the gas tank.**



Figure D

5. Install the second bracket of the Snyder skid plate as shown below, using the supplied carriage bolts and a 13mm socket (Figure E).



Figure E

6. Install the third brackets of the Snyder skid plate as shown below, using the supplied carriage bolts and a 13mm socket (Figure F).



Figure F

7. Install the fourth bracket of the Snyder skid plate as shown below, using the supplied carriage bolts and a 13mm socket (Figure G).



Figure G

8. Torque all M8 (13mm) bolts to 15-17 ft/lbs and torque all M12 (stock 18mm) bolts to 50-55 ft/lbs (Figure H).





Figure H



Before



After

Installation Instructions Written by ExtremeTerrain Customer J. Sandlin 04/11/2018