




Electronic throttle controller

User Manual



Product picture

Part 1: Functions and Specifications

1. The electronic throttle controller will adjust the throttle sensitivity based off of the user defined modes. There are (8) modes and (9) levels of sensitivity for each mode.

2. There are 8 Modes the abbreviations are listed below:

H1 - Comfortable mode

H2 - Sport mode

H3 - Racing mode

EC - Fuel-efficient mode

NOR - Normal model


SNO - Anti-skid mode

OOO - Intelligent mode

LOC - Anti-Theft mode


3. There are 9 levels (1-9) for the sensitivity. Level 1 is a slow rate of acceleration and level 9 is a fast rate of acceleration

Part 2: Installation Instructions



Installation Diagram


1. Connect the Throttle Controller with the accelerator Pedal interface
2. Stick the Throttle Controller on central console
3. Connect the plug with the Throttle Controller, bind the wire if necessary.



Picture 1

Step1:

Remove the plug from the factory throttle pedal. Please refer to picture 1




Picture 2

Step2:

Connect the throttle controller to the factory plug and the factory pedal.

Please refer to picture 2



Picture 3

Step3:

Thoroughly clean the dash location where you plan to mount the throttle controller. It is recommended to use isopropyl alcohol to remove any silicone-based products from the dashboard. If the mounting surface is not thoroughly cleaned it is possible the interface will not stick. Remove the tape backing from the user interface and firmly press it onto the dashboard.

Part 3: Safety Cautions

- a. Before the installation, user need to check the Electronic Throttle Controller plug and accelerator pedal interface, they should be connect properly.
- b. After finishing the installation, please start engine in Neutral Gear or Park Gear, and check the accelerator pedal functionality.
- c. If installed incorrectly, the pedal will not function correctly and a check engine light will appear in the gauge cluster. If in this situation, please don't worry, this product has a

internal protection circuit, which will prevent harms to the vehicle parts. Please turn off the engine and disassemble this product. After 2 minutes, install this product in the correct way, then it can work.

Part 4: Operation


- a. This product will be operated using the “Mode” and “Adjust” buttons.
- b. This product can be adjust with power at any time, but when adjusting the product, please pay attention to safety.



c. Press the Mode button  , it will show:

- H1 - Comfortable mode
- H2 - Sport mode
- H3 - Racing mode
- EC - Fuel-efficient mode
- NOR - Normal model
- SNO - Anti-skid mode
- OOO - Intelligent mode
- LOC - Anti-Theft mode



d. Adjust button  can adjust the level of the mode from weak to strong, there are 9 levels (1-9), Please note: except the NOR-Normal Mode, all of above modes have 9 levels adjustment function.

Detail for 8 mode:



Picture 4

H1 Comfortable Mode:


Increases throttle response with smooth, fast, acceleration. 1-9 level to adjust from weak to strong, picture 4 (H1.9) refer to comfortable mode and 9 level



Picture 5

H2 Sports Mode:


Improve the instantaneous acceleration, to achieve the best speed rate, 1-9 level to adjust from weak to strong, picture 5 (H2.9) refer to Sport Mode and 9 level



Picture 6

H3 Racing Mode:


Achieve the Superior acceleration performance and make it feels like in the Racing-Field. 1-9 level to adjust from weak to strong, picture 6 (H3.9) refer to Sport Mode and 9 level



Picture 7

NOR Normal Mode:


Back to the Normal control mode. Throttle pedal will function the same as factory.



Picture 8

EC Fuel-efficient Mode:

This will aid customer in achieving better fuel economy. Result will depend on driving style and habits.



Picture 9

LOC - Anti-Theft Mode:


Throttle pedal will have no response. Only to be used when the vehicle is not moving. Do not change to this setting while driving.



Picture 10

SNO - Anti-skid Mode


Suitable for snow or slippery conditions. Help reduce tire spin by delaying the throttle response at initial acceleration.



Picture 11

000 - Intelligent mode


Match the accelerate automatically according to normal driving habits



Picture 12

Automatic Mode:

Long press "Mode" button for 3 seconds, screen will show AAA, this will be used for vehicles with automatic transmissions.



Picture 13

Manual Mode:

Long press "Adjust" button for 3 seconds, screen will show SSS, this will be used for vehicles with manual transmissions.

Accessories as below:

Electronic throttle controller screen-----1pc
Accelerator pedal cable-----1pc
English manual-----1pc
Host cable-----1pc
Cable ties-----3pcs