

Tools Needed:

- Panel Removal Tool
- Flat Head Screw Driver
- T15 Torx Bit

Contents:

- (2) Headlights
- (4) Scotch Locks
- (2) LED Resistors



Step 1:

Using a panel removal tool, remove the (6) push clips holding the grille cover to the vehicle. Unplug the turn signals and remove the grille cover from the vehicle.




Step 2:

Using a flat head screw driver, carefully pry against the (3) plastic tabs holding the light into the sockets. Gently pull the headlight away from the tabs.



Step 3:


Slide the red retaining clip away from the plug. Then disconnect the plug from the headlight.



Step 4:


Using the supplied scotch locks, splice the halo wiring into the factory wiring as follows:

Side Marker Harness	-	Halo Wiring Harness
Black	-	Black
White	-	Red



Step 5:

Mount the resistor to the frame using the supplied adhesive. **Note: The resistor will get hot. Keep away from anything that may cause damage.



Step 6:

Plug the headlight harness into the LED light. Push in the red clip to lock harness in place.



Step 7:

Headlight Adjustment: Using a T15 torx bit, turn the adjuster clockwise to adjust the light up. Turn the adjuster counter-clockwise to adjust the light down.



Step 8:

Reinstall the grille in reverse order.